Tightening torques of air spring bellows mounts

Top mount / M12
Tightening torque 66 Nm

Bottom mount / M16
Tightening torque 230 Nm

Please check tightening torques regularly!

Use a torque spanner to ensure that the specified torques are accurately maintained.