



ATTENTION



Do not lower the vehicle until the air suspension system has been filled, pressurized, and calibrated according to the vehicle manufacturer's specifications.



Installation must be performed by qualified technicians only.

INSTALLATION PROCEDURE

1



Keep vehicle raised on lift after installation.

2



Fill and pressurize the air suspension system using approved diagnostic equipment.

3



Verify and calibrate vehicle ride height according to OEM specifications.

4



Lower vehicle completely and verify proper system operation.

MEYLE AG

Merkurring 111
22143 Hamburg
Germany
www.meyle.com

General notice without
constituting a legal
obligation.

Ref.-No. PAK35

MEYLE