

Anziehvorschrift für Zylinderkopf		347.087 passend für / suitable for adaptable à / adaptable a Porsche	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
10 4 2 6 8 7 5 1 3 9				
Anziehen/ Tightening/ Serrage/ Apriete		> 1985 * 20 Nm 50 Nm 90 Nm	ab 1986 20 Nm ➤ 90° ➤ 90°	
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor 102 mm Ø 924 S, Modell 1986, 4-Cyl., 2470 ccm, 110 kW (150 PS) 944, Modell 1982>1985				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*347.087*	