



Directives for installing and testing compressed air cylinders

Check that the compressed air cylinders are properly mounted and tight.

Check that the pressure drop complies with statutory regulations.
(Applicable highway code or EC Directives)

Check for corrosion and other damages.

Look at the bottom side to find the compulsory labelling (nameplate) showing the following details:

- Manufacturer
- article or order number
- factory number
- admissible working pressure (bar)
- temperature range
- content
- permit no. (type test mark)



Depressurise compressed air cylinders prior to uninstalling them. Vent the compressed air cylinder prior to installation. The compressed air cylinders are solely intended for use in motor vehicles.

