



Anziehvorschrift für Zylinderkopf		104.316	 Das Original
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a Fiat	
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
760.720 M 9x1,25x96			
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	20 Nm 30 Nm 90° 90°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ □ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage
			emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
Ø 72,0 mm			
Mot.: 188 A5.000 1.0 / 1.3 Ltr. 16V FIRE			
➔Mot.-No.: 0616937 Bravo, Brava, Palio, Punto, Stilo			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*104.316*	