



KNOW HOW

TECHNICAL BULLETIN



FITMENT GUIDE – INNER AND OUTER PADS

Correct fitment of inner and outer pads when fitted with different size or type of backplate spring

NBP1189

NBP1365

NBP1045



Outer Pad
(Caliper side)



Inner Pad
(Piston side)

Brake pad sets with inner and outer pads are often fitted with a different size or type of backplate spring. The inner and outer pads are not interchangeable.

Take care to correctly identify and fit each pad to both the inner (piston side) and outer side of the caliper. Failure to observe this can result in brake noise.

Technical Support

Contact our expert technical team
on 03333 136597 or email
NAPATECHNICAL@allianceautomotive.co.uk



TechMate Support

Book a TechMate visit today!
Contact the team on 01174 288090
or email info@techmateteam.co.uk